



UP305/UP405S DMR Two-way Radio Quick User Guide

KILISUN



Please read carefully the Safety Information and Warranty Card before using the product

Attachments



Caution for Using the Battery


- Explosion may be incurred by using a battery of a non-supplied model, or by shorting the anode and cathode of the battery.
- Charge the battery using the attached charger, and dispose it as
- Do not strike, squeeze, short out or disassemble the battery. Do not put the battery in a high temperature or throw it into a fire.
- Stop using the battery if it is seriously bulged or immersed in

Installing the Battery

- 1. Press the upper part of the belt clip gently so that it goes up. (Figure ①) 2. Align the battery with the battery holder at the back of the radio, and then insert the battery. (Figure 2)
- Push the battery in the direction indicated until the latch is in position. (Figure ③). Press the upper part of the battery until it is latched. (Figure ④).

Installing/Uninstalling the Antenna

and rotate the antenna tight clockwise. (Figure 1) To uninstall the antenna, rotate it counterclockwise. (Figure 2)




- Plug the power adapter into a qualified AC power socket.
- 4. Make sure the battery contacts the charging terminals properly and red indicator light is on.

444.9 - 444.900001, 450 - 456,

408 - 410.8,415 - 420.8,425 - 429.8,

457.5 - 458.2, 460 - 460.55,467.5 - 468.2


Insert the threaded end of the antenna into the antenna interface,



Charging the Battery

- 2. Connect the USB cable of the power adapter to the USB port at the back of the desktop charger. Green indicator light is on. 3. Insert the battery only or together with the radio into the charger.
- 5. When the indicator light turns from red to green, charging is finished. 6. After this, wait 1 to 2 hours before taking out the battery to achieve the best

1. The radio is delivered uncharged. Before using it for the first time, please charge the battery.




Align the two screw holes of the belt clip with the screws holes at the back of the radio, and screw up the screws using a screwdriver. To uninstall the belt clip, unscrew the screws and take off the belt clip.

Installing/Uninstalling Belt Clip



Installing an Earphone (Optional)

To use an earphone, open the earphone cover at the upper part of the right side of the radio, and then plug the earphone connector into the jack.



Basic Operation

1. Powering On/Off

- When the radio is off, hold down the Power/Channel knob for 3 seconds to power on the radio. You will hear a tone "di di". - When the radio is on, hold down the Power/Channel knob for 3 seconds to power off the radio. You will hear a tone "di di".


Selecting a Channel

In standby state, rotate the Power/Channel knob to select a channel. Adjusting the Volume

olume - key to decrease it. Initiating a Call to Default Group

Hold down the PTT key to initiate a call and talk, and release it to quit the call.

While working on a digital channel, the radio outputs voice when it receives an performs accordingly. individual call, group call or all call.



transmission stops and there is an alert tone, and you may cancel the tone by releasing the PTT key. After a period, you may resume transmission by holding

key programmed to scan. In standby state, press the Volume + key to increase the volume, or the V

Note: This channel is set by your dealer.

The radio receives and decodes Kill and Revive signals from another radio, and

Green indicator light is on when signals are received.

When the radio is killed, it receives no signals but Revive. While working on an analog channel, the radio outputs voice when it receives When the radio is revived, it transmits and receives signals normally.

On a digital channel, you can answer a call by holding down the PTT key within To cancel an alarm, press the Function key programmed to exit emergency alarm. the call duration. After this duration is up, you need to initiate a new call. 12. Emergency Alarm On an analog channel, you can answer a call by holding down the PTT key and Under emergency, you may send an emergency alarm by pressing the Function

key programmed to send alarms.

key programmed to send alarms.

'. Digital/Analog Switching

After configuring the mode of each channel as analog or digital, you can switch You need to set an alarm mode and an alarm type. to either mode by selecting a channel using the Power/Channel knob.

TOT (Time-out Timer) is to prevent a user from occupying a channel for too long. Emergency Alarm + Emergency Call: After the radio sends an emergency alarm, If the radio transmits continuously for a duration longer than that set by dealer, press the PTT key to initiate an emergency call.

(Note: You may have this period set by your dealer.) If a pre-alarm is enabled, you hear pre-alarm alert tone before TOT time is up.

The radio scans to search for active channels. After finding an active channel, the radio dwells on it for communication. To start/stop scan, press the Function

10. Initiating a Call during Scan

During scan, you can press the PTT key to transmit on a preset channel. can receive response from other members.

Alarm Mode Emergency Alarm: The radio sends an alarm and then exit alarm state

To cancel an alarm, press the Function key programmed to exit emergency

Note: This function is available in digital mode only, and is enabled by your dealer.

Under emergency, you may send an emergency alarm by pressing the Function

Emergency Alarm + Auto Background Tone: The radio sends an emergency alarm and then background tone.

None: Alarm is disabled. You cannot send an alarm by pressing the function key programmed to perform this function. Siren Only: In alarm state, siren plays locally and the control center cannot receive

Conventional: In alarm state, there is light and sound alert, and the radio can receive response from other members.

Secret: In alarm state, there is no light or sound alert, and the radio cannot receive response from other members. Secret with Voice: In alarm state, there is no light or sound alert, but the radio



Version: V1.0 167W06000324

radio to give off an alarm. You may set the above parameters using the programming software. To guarantee emergent communication, an emergency call is prior to a common call.

Programmable Keys

specific function as needed. Press: Press down and release quickly.

Hold down: Press down and hold for a period set through the CPS.

You may have the Function key be programmed by your dealer to perform a

NO.	Function	Description			
1	(Undefined)	Press the key, and the radio does not act.			
2	High/Low Power	If CTCSS is enabled on the current analog channel, press			
3	Monitoring				
4	Emergency Alarm	Send an emergency alarm.			
5	Exit Emergency Alarm	Quit emergency alarm state.			
6	Squelch On/Off	Enable/disable squelch. You may enable this function to receive week signals on an analog channel.			
7	Battery Level Indication	Press the key to announce the battery level.			
0	Scan	Enable/disable scan. Listen to the communication on other			

LED Indicator An emergency alarm is a non-speech signal the radio sends to trigger another Transmission in progress. Green Light on Reception in progress. Red Light Flashing Low battery. Charging is required. Green Light Flashing Scan in progress.

Yellow Light Flashing In call hold state in digital mode. Exit when hold time is up. Yellow Light on The channel is not configured. Switch to another channel. lcons (UP405S only)

Icon	Description			
	Current channel. (16 channels in total)			
# I	Volume level. (14 levels in total)			
# 3K	Mute state.			
	Low-battery alarm. (Remaining capacity < 5%)			
	Remaining battery capacity. (High, medium or low)			
2	The zone of the current channel. (16 zones in total)			
	Calling in progress			

"	3	CTCSS), and the radio outputs voice if carriers are matched.			i i Ine	e zone of the current channel. (16 zones in total)	
4		,, ,				alling in progress.	
4	Emergency Alarm	Send an emergency alarm.			<u> </u>		
5	Exit Emergency Alarm	Quit emergency alarm state.		3 -	Troubleshooti	na	
6	Squelch On/Off	Enable/disable squelch. You may enable this function to receive week signals on an analog channel.				··9	
7	Battery Level Indication	Press the key to announce the battery level.		No.	Problem	Reason and Solution	
8	Scan	Enable/disable scan. Listen to the communication on other					
		channels.		١.		1. Battery out	
9	Alert Tone On/Off	Enable/disable alert tones.		1	Power-on failur	Solution: Charge or replace the battery. 2. Faulty volume switch	
10	Zone Selection	Switch to another zone. Zones are programmed using the CPS.				Solution: Get it repaired at the authorized service station.	
11	Repeater/Talk Around	Enable/disable repeater function for the channel.			Low voice during	1. Speak too far from the microphone Solution: Keep a distance of 3~10 cm from the microphone.	
12	Nuisance Delete	Press the key to delete an unwanted channel from the scan list.		2	call	Wrong volume setting Solution: Rotate the volume knob clockwise to increase the volume.	
13	Broadcast Call	Make a broadcast call.				Wrong channel parameters	
				3	Failed to transr or receive	Solution: Set the parameters properly and try again.	
					I.		

Kirisun directive (EU) No 2014/53 of the European Parliament and of the Council of 16 April 2014 on harmonisation of the laws of the Member States Kirisun directive (EU) No 2014/53 of the

Restrictions Fre	equencies are valid for the Europea	n country
Country	Max. transmit power(W)	
Germany(DE)	406.1-430 ,440-470	4
France (FR)	406.1-430,444.5-447, 451.5-460, 461.5-470	4
United Kingdom (UK	410-430 ,440-470	4
Italy(IT) 440-443,445-470		4
Greece(EL) 406.1-430 ,440-470		4
Spain(ES)	406.1-430 ,440-470	4
Ireland (IE)	410 - 430,440 - 455, 456 - 459,460 - 470	4
Belgium(BE)	406.1-430 ,440-470	4
Croatia (HR)	406.1-430 ,440-470	4
Cyprus (CY)	406.1-430 ,440-470	4
Portugal (PT)	440-470	4
Malta(MT)	406.1-430 ,440-470	4
Luxembourg (LU)	410-430,440- 470	4
Bulgaria(BG)	410 -430,440-470	4
Latvia (LV)	406.1-430,440-450,456 -470	4
Slovenia(SI)	406.1-430 ,440-470	4
Czech Republic(CZ)	448 - 451.3,457.38 - 461.3,467.38 - 470	4

Notice to user

Poland(PL) 448 - 449.5,457 - 460,467 - 470 European Parliament and of the Council of 16 April 2014 on harmonisation of the Romania (RO) 440 -450.55,

Country	Frequency Range(MHz)	Max. transmit power(W)		
Germany(DE)	406.1-430 ,440-470	4		
France (FR)	406.1-430,444.5-447, 451.5-460, 461.5-470	4		
United Kingdom (UK	410-430 ,440-470	4		
Italy(IT)	440-443,445-470	4		
Greece(EL)	406.1-430 ,440-470	4		
Spain(ES)	406.1-430 ,440-470	4		
Ireland (IE)	410 - 430,440 - 455, 456 - 459,460 - 470	4		
Belgium(BE)	406.1-430 ,440-470	4		
Croatia (HR)	406.1-430 ,440-470	4		
Cyprus (CY)	406.1-430 ,440-470	4		
Portugal (PT)	440-470	4		
Malta(MT)	406.1-430 ,440-470	4		
Luxembourg (LU)	410-430,440- 470	4		
Bulgaria(BG)	410 -430,440-470	4		
Latvia (LV)	406.1-430,440-450,456 -470	4		
Slovenia(SI)	406.1-430 ,440-470	4		
Czech Republic(CZ)	448 - 451.3,457.38 - 461.3,467.38 - 470	4		

Denmark(DK) 406.1-430,450 - 470

Netherlands(NL) 410 -430,440-470

Estonia(EE) 442.5, 443 - 450,446 -446.2,450 -453,457.575

Hungary(HU) 417 - 420,442 - 445,456 - 460, 461.3 - 470

406.1 - 410,412.5 - 420, 422.5-430,440 -

Restrictions Frequencies are valid for the European country				SK)	441.025 - 451.31,455.73 - 461.31,465.73- 470		
Country	Frequency Range(MHz)	Max. transmit power(W)			407.525 - 408.55,410.0125 - 410.8875,417.525 - 417.9, 419.15 - 419.525,419.55625 -419.71875,		
Germany(DE)	406.1-430 ,440-470	4			420.0125 - 420.8875,426.35 -427.5,		
France (FR)	406.1-430,444.5-447, 451.5-460, 461.5-470	4			427.525 - 427.9, 429.15 -429.525, 429.55625- 429.71875,440.0125 -440.5875,		
United Kingdom (UK	410-430 ,440-470	4	Finland(F	I)	440.60625 - 440.89375,442.775 - 443, 443.025 - 444.444.025 - 444.525, 444.55 - 444.975,445 - 446, 447.00625 - 447.29375,447.30625 - 447.70625, 449.025 - 449.525,449.55 - 449.975, 450.325 - 452.475,452.525 - 452.975,		
Italy(IT)	440-443,445-470	4					
Greece(EL)	406.1-430 ,440-470	4					
Spain(ES)	406.1-430 ,440-470	4			453.0125 -453.6625,469.725 - 469.975		
Ireland (IE)	410 - 430,440 - 455, 456 - 459,460 - 470	4	Sweden(S	SE)	406.1 -430, 442 - 444,444.5875 - 452.5, 457.5 - 462.5,467.5 - 470		
Belgium(BE)	406.1-430 ,440-470	4	Destrictions are valid for the Function of the		alid for the Common accordance		
Croatia (HR)	406.1-430 ,440-470	4	Restrictions are valid for the European country Restrictions are valid for the following countries: France (FR), United Kingdom (UK), Italy(IT), Ireland (IE), Por				
Cyprus (CY)	406.1-430 ,440-470	4					
Portugal (PT)	440-470	4					
		 	Luxembou	ra (LU)	. Bulgaria(BG) . Latvia (LV). Czech Republi		

must not be disposed of as household or commercial waste. Some countries have set up collection and recycling systems for waste electrical and electronic duct and its packaging is disposed of correctly, you will — Reorient or relocate the receiving antenna. help prevent potentially negative consequences for the environment and human health, and help conserve natural resources. Please dispose of your waste product according to your national and local regulations. Contact your service provider or Kirisun for information about disposing of this product in your region of the world.

your region of the world.

FCC& IC radiation exposure statement 427.525 - 427.9, 429.15 -429.525, 429.55625- 429.71875,440.0125 -440.5875 444.55 - 444.975,445 -446, 447.00625 - 447.29375,447.30625 -447.70625

Sweden(SE) 406.1 -430, 442 - 444,444.5875 - 452.5, 457.5 - 462.5,467.5 - 470 strictions are valid for the European country

strictions are valid for the following countries: rance (FR), United Kingdom (UK), Italy(IT), Ireland (IE), Portugal (PT), Luxembourg (LU), Bulgaria(BG), Latvia (LV), Czech Republic (CZ), Denmark(DK), Estonia(EE), Lithuania(LT), Hungary(HU), Netherlands(NL),

Waste Electrical and Electronic Equipment recycling This symbol on the product or its packaging indicates that this product

Your radio is supplied with a rechargeable lithium-ion battery. This symbol on the battery and its packaging indicates that it must not be disposed of with household or commercial waste. Please dispose of your waste batteries according to your national and local regulations. Contact your service provider or Kirisun about recycling batteries in

Any Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

following two conditions: (1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

encouraged to try to correct the interference by one or more of the following

US Markets

This device complies with part 15 of the FCC Rules. Operation is subject to the

designed to provide reasonable protection against harmful interference in a frequency energy and, if not installed and used in accordance with the Austria(AT), Poland(PL), Romania (RO), Slovakia(SK), Finland(FI), Sweden(SE) instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation.

• Ne retirez pas l'étiquette d'exposition RF de l'appareil. which can be determined by turning the equipment off and on, the user is

 Increase the separation between the equipment and receiver. to which the receiver is connected.

Consult the dealer or an experienced radio/TV technician for help.

aware of the hazards, and the ways to minimize such hazards; NOT intended for use in an General population /uncontrolled environment. - DO NOT operate the radio without a proper antenna antenna attached, as this may damage the radio and may also cause you to exceed RF exposure limits. A proper antenna is the antenna supplied with this radio by the manufacturer or an antenna specifically authorized by the manufacturer for use with this radio. - DO NOT transmit for more than 50% of total radio use time, more than 50% of Mode d'emploi:

the time can cause RF exposure compliance requirements to be exceeded. - This transmitter may operate with the antenna(s) documented in this filing in Push-to-Talk and body-worn configurations. RF exposure compliance is limited to the specific belt-clip and accessory configurations as documented in this filing and the separation distance between user and the device or its antenna shall be at least 25mm and 0mm from your body.

All qualified end-users of this device must have the knowledge to control their

exposure conditions and/or duration to comply with occupational/controlled Note: This equipment has been tested and found to comply with the limits for a

Exposure limit and requirements. The highest reported SAR values for Face-held,

If this equipment does cause harmful interference to radio or television reception, Les instructions de sensibilisation de l'utilisateur doivent accompagner l'appareil contrôlé. lorsqu'il est transféré à d'autres utilisateurs.

Mode d'emploi: Ne transmettez pas plus que le facteur de service nominal de 50% du temps. — Connect the equipment into an outlet on a circuit different from that Pour transmettre (parler), appuyez sur le bouton Push-To-Talk (PTT). Pour recevoir des appels, relâchez le bouton PTT. La transmission à 50% du temps, ou moins, est importante car cette radio génère une exposition à l'énergie RF mesurable uniquement lors de la transmission (en termes de mesure de

pas satisfaites.

conformité aux normes).

- This radio is designed for and classified as "Occupational/Controlled Use Only", milieu professionnel / contrôlé, respectez toujours les procédures suivantes.

 Ne retirez pas l'étiquette d'exposition RF de l'appareil. · Les instructions de sensibilisation de l'utilisateur doivent accompagne l'appareil lorsqu'il est transféré à d'autres utilisateurs. N'utilisez pas cet appareil si les exigences opérationnelles décrites ici ne sont

conformité aux normes).

• Ne transmettez pas plus que le facteur de service nominal de 50% du temps. Pour transmettre (parler), appuyez sur le bouton Push-To-Talk (PTT). Pour recevoir des appels, relâchez le bouton PTT. La transmission à 50% du temps, ou moins, est importante car cette radio génère une exposition à l'énergie RF mesurable uniquement lors de la transmission (en termes de mesure de

aux RF diminuent avec la distance de l'antenne. L'antenne doit être éloignée training information for meeting occupational exposure requirements. The highes residential installation. This equipment generates, uses and can radiate radio

Pour contrôler votre exposition et garantir le respect des limites d'exposition en

• Lorsqu'elle est portée sur le corps, placez toujours la radio dans un clip, un milieu professionnel / contrôlé, respectez toujours les procédures suivantes. support, un étui, un étui ou un harnais de sécurité approuvés pour ce produit. L'utilisation d'accessoires non approuvés peut entraîner des niveaux d'exposition

> Utilisez uniquement les antennes, batteries et accessoires fournis ou de N'utilisez pas cet appareil si les exigences opérationnelles décrites ici ne sont remplacement approuvés par le fabricant. L'utilisation d'antennes, de batteries et d'accessoires non approuvés par le fabricant peut dépasser les directives d'exposition RF FCC et IC.

> > Pour obtenir une liste des accessoires approuvés, veuillez consulter votre

qui dépassent les limites d'exposition aux RF de l'environnement professionnel /

revendeur local pour plus d'informations. The information listed above provides the user with information needed to make him or her aware of a RF exposure, and what to do to assure that this radio operates within the RSS-102 exposure limits of this radio.

Pour contrôler votre exposition et garantir le respect des limites d'exposition en Output power listed is rated conducted. This device must be restricted to work-related operations only in an Occupational/Controlled RF exposure

environment and must operate with a duty factor not exceeding 50%. This transmitter may operate with the antenna(s) documented in this filing in Push-to-Talk and body-worn configurations. The device complies with RF specifications when the device used at 25 mm from your front face and 0 mm from your body. All qualified end-users of this device must have the knowledge to control their exposure conditions and/or duration to comply with occupational/ controlled Exposure limit and requirements. A label, as described in this filing, must be displayed on the device to direct users to specific training information for meeting occupational exposure requirements. This portable radio generates RF electromagnetic energy during transmit mode. This radio is designed for and classified as "Occupational Use Only," meaning it must be used only during the course of employment by individuals aware of the hazards and the ways to minimize such hazards. This radio is NOT intended for use by the "General • Tenez la radio en position verticale devant le visage avec le microphone (et les must have the knowledge to control their exposure conditions and/or duration to autres parties de la radio, y compris l'antenne) à au moins 2,5 cm (2,5 cm) du comply with occupational/controlled Exposure limit and requirements. A label, as nez. Il est important de garder la radio à la bonne distance car les expositions described in this filing, must be displayed on the device to direct users to specific reported SAR values for Face-held, body-worn are 3.529 W/Kg, 6.285 W/Kg.

> Kirisun reserves the right to the final interpretation of this document. This document is only for reference, and actual product prevails.

成型 尺寸: 165*95mm